Function list for VRF

External input and output function/External connect kit

Type		Refrigerant	Indoor unit																	Outdoor unit					controller	Other
			Cassette					Duct					Floor		Floor/Ceiling		Wall-mounted									
			One-way flow	3D flow	Compact grid type/ Standard type	Slim type	Large type	Low static pressure			Medium static pressure	High static pressure	-	EEV external			-	EEV external	-	J-IVL	J-IV	J-IVS	V-IV	VR-IV	Central remote controller	RB unit
						Circular flow		Mini (With drain pump)	Slim (With drain pump)	High Efficiency	Normal	Normal														
		R410A	AUXV 004/007/009/ 012/014/018/ 024GLEH	AUXS 018/024 GLEH	AUXB 004/007/009/ 012/014/018/ 024GLEH	AUXM 018/024/030 GLEH	AUXK 018/024/030/ 034/036/045/ 054GLEH	ARXK 004/007/009/ 012/014/018/ 024GLGH	ARXD 007/009/012/ 014/018/024 GLEH, ARXD 04GALH	ARXP 018/030 GLFH	ARXA 024/030/ 036/045 GLEH	ARXC 036/045/060 072/090/096 GTEH	AGYA 004/007/ 009/012/014 GGGH	AGYE 004/007/ 009/012/014 GCEH	ABYA 012/014/018/ 024GTEH	ABYA 030/036/045/ 054GTEH	ASYA 004/007/009 012/014 GCGH	ASYE 004/007/009 012/014 GCEH	ASYA 18/24GBCH	ASYA 030/034GTEH	AJY 072/090/108/ 126/144/162 LELDH	AJY 040/045/054 LBLDH, AJY 040/045/054 LELDH	AJY 040/045/054 LCLDH	AJY 072/090/108/ 126/144/162 LALDH	AJY 072/090/108/ 126/144 GALDH	UTY-DCGYZ2	UTP-RX01AH UTP-RX01BH UTP-RX01CH UTP-RX04BH UTP-RX08AH UTP-RX12AH
Input	Operation/Stop		● UTY-XWZXZD ○ UTY-XWZXZB														● UTY-XWZXZD ○ UTY-XWZXZB									
	All On/All Off																								●UTY-XWZXZ7 ○UTY-XWZXZ8	
	Group stop																			● UTY-XWZXZ6						
	Forced stop		● UTY-XWZXZD ○ UTY-XWZXZB														● UTY-XWZXZD ○ UTY-XWZXZB									
	Emergency stop		● UTY-XWZXZD ○ UTY-XWZXZB														● UTY-XWZXZD ○ UTY-XWZXZB			● UTY-XWZXZ6					●UTY-XWZXZ7 ○UTY-XWZXZ8	
	Forced thermostat off		● UTY-XWZXZE ○ UTY-XWZXZ7														● UTY-XWZXZE ○ UTY-XWZXZ7									
	Low noise mode operation																			● UTY-XWZXZ6						
	Cooling/ Heating priority																			● UTY-XWZXZ6						●UTY-XWZXZ6 ○UTY-XWZXZB
	Outdoor unit operation peak control																			● UTY-XWZXZ6						
	Power usage information from electricity meter																			● UTY-XWZXZF						
Output	Operation status		● UTY-XWZXZC														● UTY-XWZXZC			○ UTY-XWZXZ6					○UTY-XWZXZA	
	Error status		● UTY-XWZXZC														● UTY-XWZXZC			○ UTY-XWZXZ6					○UTY-XWZXZA	
	Indoor unit fan operation status		● UTY-XWZXZC														● UTY-XWZXZC									
	Auxiliary heater output							● UTY-XWZXZC																		
	Base pan heater																			● UTY-XWZXZ9			● UTY-XWZXZ9			

*2: The Touch panel controller has the functions of dry contact and voltage application, but the external connection kit described above is not necessary because the touch panel controller has an external input terminal block.

●: Dry Contact ○: Apply Voltage

Communication system

External connect kit

For indoor unit

UTY-XWZXZ7

UTY-XWZXZD

UTY-XWZXZB

UTY-XWZXZE

UTY-XWZXZC

For outdoor unit

UTY-XWZXZ6

UTY-XWZXZ9

UTY-XWZXZF

For RB unit

UTY-XWZXZ6

UTY-XWZXZB

Central remote controller

UTY-XWZXZ7

UTY-XWZXZ8

UTY-XWZXZA

For Touch panel controller

UTY-XWZXZA