

**OPERATING MANUAL  
BEDIENUNGSANLEITUNG  
MODE D'EMPLOI  
MANUAL DE FUNCIONAMIENTO  
MANUALE DI FUNZIONAMENTO  
ΕΓΧΕΙΡΙΔΙΟ ΧΡΗΣΗΣ  
MANUAL DE INSTRUÇÕES  
РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ  
İŞLETME KILAVUZU  
使用説明書**

English

Deutsch

Français

Español

Italiano


Ελληνικά

Portugués

Русский

Türkçe

中国語



**KEEP THIS MANUAL FOR FUTURE REFERENCE**

**HEBEN SIE DIESES HANDBUCH FÜR ZUKÜNFTIGE REFERENZEN SORGFÄLTIG AUF**

**CONSERVEZ CE MANUEL POUR RÉFÉRENCE ULTÉRIEURE**

**CONSERVE ESTE MANUAL PARA SU FUTURA CONSULTA**

**CONSERVARE QUESTO MANUALE PER USARLO IN FUTURO**

**ΚΡΑΤΗΣΤΕ ΑΥΤΟ ΤΟ ΕΓΧΕΙΡΙΔΙΟ ΓΙΑ ΝΑ ΑΝΑΤΡΕΞΕΤΕ ΣΕ ΑΥΤΟ ΑΡΓΟΤΕΡΑ**

**GUARDE ESTE MANUAL PARA REFERÊNCIA FUTURA**

**СОХРАНИТЕ ДАННОЕ РУКОВОДСТВО ДЛЯ ПОСЛЕДУЮЩЕГО ИСПОЛЬЗОВАНИЯ**

**BU KILAVUZU DAHA SONRA BAŞVURMAK ÜZERE SAKLAYIN**

**請保存本說明書以供日後參考。**


**PART NO. 9374142170-03**


# CONTENTS

SAFETY PRECAUTIONS .....	En-1	ERROR CODE DISPLAY .....	En-4
NAME OF PARTS .....	En-2	TROUBLESHOOTING .....	En-4
OPERATION .....	En-3		


## SAFETY PRECAUTIONS

- Before using the appliance, read these “SAFETY PRECAUTIONS” thoroughly and operate in the correct way.
- The instructions in this section all relate to safety; be sure to maintain safe operating conditions.
- “WARNING” and “CAUTION” have the following meanings in these instructions:


 <b>WARNING</b>	<p>This mark indicates procedures which, if improperly performed, are most likely to result in the death of or serious injury to the user or service personnel.</p>
<ul style="list-style-type: none"> <li>● Do not attempt to install this controller by yourself.</li> <li>● This controller contains no user-serviceable parts. Always consult authorized service personnel for repairs.</li> <li>● When moving, consult authorized service personnel for disconnection and installation of the controller.</li> <li>● If a problem (burning smell, etc.) occurs, turn off the electrical breaker immediately to stop operation, and then consult authorized service personnel.</li> <li>● If the wiring cord is damaged, contact your service representative for instruction.</li> </ul>	

 <b>CAUTION</b>	<p>This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user or damage to property.</p>
<ul style="list-style-type: none"> <li>● Do not expose the controller directly to water.</li> <li>● Do not operate the controller with wet hands.</li> <li>● Do not touch the switches with sharp objects.</li> <li>● Always turn off the electrical breaker whenever cleaning the controller, the air conditioner or the air filter.</li> <li>● Check the condition of the installation stand for damage.</li> <li>● Ensure that any electronic equipment is at least away from the controller.</li> <li>● Avoid installing the controller near a fireplace or other heating apparatus.</li> <li>● When installing the controller, take precautions to prevent access by infants.</li> <li>● Do not use inflammable gases near the controller.</li> </ul>	

# NAME OF PARTS



## • Display panel



- ① “ ⏻ / | ” (START/STOP Button)
- ② “ ⏴ ⏵ ”, “ ⏴ ▲ ” (Set Temperature Button)
- ③ “ ⏴ ” (Fan Control Button)
- ④ “ ⏴ ⏵ ⚙ ” (Operation Mode Button)
- ⑤ START/STOP LED
- ⑥ Electric energy Display
- ⑦ Standby Display
- ⑧ Operation Lock Display
- ⑨ Fan Speed Display
- ⑩ Temperature Display
- ⑪ Error Display
- ⑫ Operation Mode Display

Depending on the indoor unit model, some buttons on this remote controller cannot be used and some functions are restricted.


Refer to the operation manual on the indoor unit.

# OPERATION

Instructions relating to heating are applicable only to "HEAT & COOL MODEL" (Reverse Cycle).

Preset values are displayed when the "❄️🌀" button, the "🔼" button or "🔽" button, the "🌀" button is pressed while stopping.

## To start/stop operation



Press the "🔌" button.

### START/STOP LED

Air conditioner ON: Lit brightly  
Air conditioner OFF: Not lit


Blinking of START/STOP LED means occurrence of an error. Please refer to "ERROR CODE DISPLAY" in the manual.

## To set the operation mode


### ● Operation mode setting



Press the "❄️🌀" button to set the operation mode.  
If DRY is selected, the fan speed will be set to AUTO.



### ● Room temperature setting



Press the "🔼" button or "🔽" button to set the room temperature.


### Temperature setting range

AUTO .....	18 to 30°C
COOL/DRY .....	18 to 30°C
HEAT .....	16 to 30°C

### ● Fan speed setting



Press the "🌀" button to select the fan speed while in operation.



## i NOTES

- (1) Display panel lights up.
- (2) When **🔌** is displayed, there are functions for which settings cannot be made.  
When a button is pushed to change a restricted setting, **🔌** will flash.
- (3) During Automatic Defrosting operation and Oil Recovery operation, **🔌** will be displayed on the remote controller.
- (4) When connecting with other controllers, the indoor unit might be controlled by the other controllers.
- (5) The wired remote controller or the wireless remote controller can also be used with this unit.
- (6) Simultaneous use of multiple units.

Operation cannot be done in the following different operating modes.


If the indoor unit is instructed to do an operating mode that it cannot perform, **🔌** will be shown on the remote controller display and the unit will go into the standby mode.

- Heating mode and cooling mode (or dry mode).
- Heating mode and fan mode.

# ERROR CODE DISPLAY

This appears automatically on the display if an error occurs.

If an error occurs, the following display will be shown.  
 ("Er" will appear in the set room temperature display.)  
 If "Er" is displayed, immediately contact authorized service personnel.  
 Do not use the operation as shown to the right if an error has occurred. Occurrence of an error is indicated by the blinking of START/STOP LED.



Ex. Error code display

# TROUBLESHOOTING

Instructions relating to heating are applicable only to "HEAT & COOL MODEL" (Reverse Cycle).

## ⚠ WARNING

- In the event of a malfunction (burning smell, etc.), immediately stop operation, turn off the electrical breaker and consult authorized service personnel.
- Merely turning off the unit's power switch will not completely disconnect the unit from the power source.
- Always be sure to turn off the electrical breaker to ensure that power is completely off.

Before requesting service, perform the following checks:

	Symptom	Cause and Action
CHECK ONCE MORE	Doesn't operate at all.	<ul style="list-style-type: none"> <li>• Has there been a power failure?</li> <li>• Has a fuse blown out, or a circuit breaker been tripped?</li> <li>• Is the main power switch set to the OFF position?</li> </ul>
		<ul style="list-style-type: none"> <li>• Is the timer operating?</li> </ul>

If the problem persists after performing these checks, or if you notice burning smells, stop operation immediately, turn off the electrical breaker, and consult with authorized service personnel.

